

# Transition



*Rough Opening with Wood Buck  
Installation using Joint & Seam  
Filler, FastFlash, and Cat 5*

[www.prosoco.com](http://www.prosoco.com)

PROSOCO  
SINCE 1939

